



Nr.	1	2	3	4	5	6	7	8	9	10	11	12
Name	C0	R0	C1	R1	C2	R2	C3	R3	C4	R4	GND	3V3





Keyboard Control

Nr.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Name	A1	VAP	A2	GND	A3	A0	A4	B0	C0	B1	C1	D0	E0	D1	F0	G0	F1	G1	F2	G2	F3	G3	F4	G4




Voice Control


Fine Control
Coarse Control




PWM Control



Gain Control




Cut-off Control



Rotary Switch Table


Pin/Switch Name	Signal	Filter	Offset
COM	F4	G0	A0
1	F0	G1	A1
2	F1	G2	A2
3	F2	G3	A3
4	F3	G4	A4

Nr.	1	2	3	4	5	6	7	8	9	10	11	12
Name	R1	VOL1	P1	VOL2	R2	BPM	P2	BLED	RLED	BBTN	GND	3V3




Seq & Volume Control


Volume Control



BPM Control



BPM/Rec LED



Buttons Divers

